



CH150 OWNER'S MANUAL

ELITE 150



1985 HONDA

1985 HONDA



ELITE 150

CH150 MANUEL DU CONDUCTEUR

32KN7600

00X32-KN7-6000

カナダ 英 日 10008501F PRINTED IN JAPAN

NOTICE IMPORTANTE

- **CONDUCTEUR ET PASSAGER**

Cette scooter est conçue pour transporter le conducteur et un passager. Ne jamais dépasser la capacité de charge du véhicule indiquée sur l'étiquette de renseignement des pneus.

- **EMPLOI SUR ROUTE**

Cette scooter est spécifiquement conçue pour un usage sur route.

- **LIRE ATTENTIVEMENT LE MANUEL DU CONDUCTEUR**

Tenir spécialement compte des explications précédées des titres suivants:

ATTENTION

Signale un risque important d'accident corporel grave, voire mortel s'il n'est pas tenu compte des instructions.

PRECAUTION


Signale un risque d'accident corporel ou de détérioration du véhicule s'il n'est pas tenu compte des instructions.

NOTE: Fournit des renseignements utiles.

Ce manuel doit être considéré comme faisant partie intégrante du véhicule et doit l'accompagner à la revente de celui-ci.

HONDA CH150 ELITE 150 MANUEL DU CONDUCTEUR

30909 711 1985



Tous les renseignements fournis dans cette brochure ont été compilés à partir des renseignements techniques les plus récents disponibles au moment de la mise sous presse. La société HONDA MOTOR CO., LTD. se réserve le droit d'apporter à tout moment des modifications sans fournir de préavis et sans engagement particulier.

Toute reproduction; même partielle, de cet ouvrage est interdite sans avoir obtenu préalablement un accord écrit.

IMPORTANT NOTICE

- **OPERATOR AND PASSENGER**

This scooter is designed to carry the operator and one passenger. Never exceed the vehicle capacity load as shown on the tire information label.

- **ON-ROAD USE ONLY**

This scooter is designed to be used only on the road.

- **READ THIS OWNER'S MANUAL CAREFULLY**

Pay special attention to statements preceded by the following words:

WARNING

Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.


Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

This manual should be considered a permanent part of the scooter and should remain with the scooter when resold.

HONDA CH150 ELITE 150 OWNER'S MANUAL

1985



All information in this publication is based on the latest product information available at the time of approval for printing. HONDA MOTOR CO., LTD. reserves the right to make changes at any time without notice and without incurring any obligation. No part of this publication may be reproduced without written permission.

WELCOME,

Your new scooter presents you with an invitation to adventure and a challenge to master the machine. Your safety depends not only on your own alertness and familiarity with the scooter, but also the scooter's mechanical condition. A pre-ride inspection before every outing and regular maintenance are essential.

To help meet the challenges safely and enjoy the adventure fully, become thoroughly familiar with this Owner's Manual BEFORE YOU RIDE THE SCOOTER. Also, for your own and your Honda's sake, please read all the written material which came with your new Honda. These items include:

- * Honda Owner's Identification Card
- * Set-up and Predelivery Checklist
- * Honda Motor Scooter Emission Control System, Distributor's Warranty
- * Honda Motor Scooter, Distributor's Limited Warranty
- * Honda Motor Scooter Noise Control Systems, Distributor's Warranty.

When service is required, remember that your authorized Honda scooter dealer knows what it takes to keep your Honda going strong. If you have the required mechanical "know-how" and tools, your authorized Honda scooter dealer can supply you with an official Honda Scooter Shop Manual to help you perform many maintenance and repair tasks.

Pleasant riding and thank you for choosing a Honda!

OPERATION

Page		Page	
1	SCOOTER SAFETY	21	Starter Button
3	Safe Riding Rules	22	Left Handlebar Controls
4	Protective Apparel	23	Rear Brake Lock
4	Modifications		
5	Loading and Accessories	24	FEATURES (Not required for operation)
6	PARTS LOCATION	24	Steering Lock
9	Parts Function	24	Seat Lock
		25	Helmet Holder
13	MAJOR COMPONENTS (Information you need to operate this scooter)	26	Glove Box
13	Brakes	27	OPERATION
14	Coolant	27	Pre-ride Inspection
16	Fuel	28	Starting the Engine
17	Engine Oil Level Check	32	Brake-in
18	Tubeless Tires	33	Riding
		36	Braking
20	ESSENTIAL INDIVIDUAL COMPONENTS	37	Parking
20	Ignition Switch	37	Anti-theft Tips
21	Engine Stop Switch		

MAINTENANCE

Page		Page	
38	MAINTENANCE	55	ELECTRICAL
39	Maintenance Schedule	55	Battery
41	Maintenance Record	57	Fuse Replacement
42	Tool Kit		
43	Serial Numbers	58	TRANSPORTING
44	Color Label	59	CLEANING
45	Maintenance Precautions		
46	FILTERS/LUBRICATION	60	STORAGE GUIDE
46	Air Cleaner		
47	Crankcase Breather	62	SPECIFICATIONS
48	Engine Oil		
51	ENGINE		
51	Spark Plug		
52	Idle Speed		
53	FRAME/BRAKES		
53	Brake Shoe Wear		
54	Side Stand		

SCOOTER SAFETY

Read these WARNING LABELS before you ride!

